




EOS™

PRECISION RUBBER BAND SYSTEM™

WARNING:
Do not aim at eyes or face. TO AVOID
INJURY: Use only rubber bands designed
for the product. Do not modify rubber bands.

CAUTION:
This product contains Natural Rubber Latex
which may cause allergic reactions.



INSTRUCTIONS FOR MAXIMUM PERFORMANCE!

THIS IS GOING TO BE FUN!

For the best performance, please follow these simple steps for loading, aiming, and launching.

To consistently get the best accuracy and range, load as instructed.

The RBS rubber bands included, and available in refill packs, are formulated for maximum performance. These are standard size rubber bands, designated by size #8. Ordinary rubber bands of the same size # can also be used.

See the size chart below.

It is really important how you load the bands. Load them correctly, and with a little practice, you'll launch far and hit what you are aiming at. Load them incorrectly, and you'll be beaten every time by the person that does it right.


LOADING

EOS features BURST action that can launch one band at a time or up to six #8 rubber bands in very quick succession.


Hook the end of the band over the orange nock at the front. Using two fingers, pull the band to the back of the burst comb. (see FIG. 1)



Position the band at the very end of the burst comb and release so the band is stretched between the nock and the comb. (see FIG. 2)



Repeat this method to load 6 bands, starting at the furthest slot from the nock, on each slot on the comb, to the closest. (see FIG. 3)




You can load up to six of the #8 bands.

CAUTION: Loading more than six #8s can prevent the EOS from functioning properly!

AIM/LAUNCH

THIS IS WHERE IT GETS GOOD!
To aim, first lift the clear shield to its top-most position. (see FIG. 4)



Peering thru the shield, look straight down the barrel. Align your sight so the tip of the orange spoke is directly lined up with the cross-hair on the shield. Find the center of your target, then aim slightly lower than center (about 2 inches/5 cm).

Aiming slightly low compensates for the natural flight of the band. When ready, pull the trigger and launch!

The burst launch is FAST! Practice to master control. Pull fast and all the bands will launch very quickly. Pull back slowly and controlled, and you can launch one at a time.

EXTRA AMMO

To carry extra #8 ammo, wrap bands around the cleat on the bottom.

TIPS

- For the highest precision launching, wash new rubber bands with soapy water and dry before using them. This will create more friction and the best asymmetrical tension.
- Give new bands a few stretches to help break them in. This helps them fly more reliably.
- Check rubber bands for cuts, nicks and defects after repeated launching and retire those weary bands to prevent unexpected breaks.

Have fun, but PLEASE BE SAFE!

NEVER point Precision RBS at any person or animal (plants and trees are ok).

NEVER EVER launch toward face or eyes.

DO NOT attempt to modify rubber bands or launcher in any way.

DO NOT put any objects other than the specified rubber bands provided and recommended into the Precision RBS. DO NOT give the product to children under the recommended age. Children should use under parental supervision.

WARNING:

Not suitable for children under 3 years due to small parts.



Super Impulse Limited
Unit 612-615, 6th Floor, Peninsula Centre
87 Mody Road, Tsimshatsui East
Kowloon, Hong Kong

FOR MORE VISIT

WWW.PRECISIONRBS.COM



CHOKING HAZARD
Small parts.
Not for children
under 3 years.

Product colors and specifications subject to change.
U.S. AND WORLDWIDE PATENTS PENDING
© 2016 Super Impulse Limited. ALL RIGHTS RESERVED.
RBS LOGOS ARE TRADEMARKS OF Super Impulse USA, L.L.C.

117/150 MM

33/50 MM

16/50 MM

8/20 MM

RUBBER BAND SIZE CHART